CABINET PARTS

REFRIGERATOR

For Models: MSD2258KGW01, MSD2258KGB01, MSD2258KES01, MSD2258KEU01

(White) (Black) (Stainless) (Stainless VCM)

MAYTAG



IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

CABINET PARTS

For Models: MSD2258KGW01, MSD2258KGB01, MSD2258KES01, MSD2258KEU01
(White) (Black) (Stainless) (Stainless VCM)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	2326267	Use & Care Guide
	2305869	Service & Wiring Sheet
	W10120265	Energy Guide
	2220407	Modular Icemaker Service Sheet
	2261037	Instruction Sheet, Door Removal
2	2174748	Front Roller (2)
3	3400517	Screw
4	2196236	Rear Roller (2)
5	489427	Screw
6	2155013	Clip, Grille
7	489478	Screw
8	2186443	Housing, Water Filter
9	2209697	Shim (2)
10	2203770	Hinge Top, FC
11	2203771	Hinge Top, RC
12		Hinge Cover, FC
	2203407W	White
	2203407B	Black
13	2304322	Hinge Bottom (2)
14		Filler, Wrapper
	2304846	White
	2304848	Black
15		Grille
	2198467W	White
	2198467B	Black
16	489497	Screw
17	489464	Screw
18	2304888	Drain Fitting
19	2304937	Extension Tube
20	8212652	Water Filter
21	2188734	Cover, Unit
22		Hinge Cover, RC
	2203408W	White
	2203408B	Black
23	549193	Clamp, Service Cord
24	489084	Screw
25	2155311	Door Closer, Lower Cam (2)
26	489483	Screw
27	489500	Screw
28		Cap, Water Filter
	2186494W	White
	2186494B	Black
29		Cabinet (Not A Serviceable Part
30	8281227	Screw
31	3400113	Screw (4)
32	2186489	Block, Housing Support
33	2304708	Tube, Filter Outlet
34	2319867	Tube, Filter Inlet

IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

REFRIGERATOR LINER PARTS

For Models: MSD2258KGW01, MSD2258KGB01, MSD2258KES01, MSD2258KEU01
(White) (Black) (Stainless) (Stainless VCM)



Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2194744	Escutcheon, Meat Pan Control
3	2182757	Slide Meat Pan Control
4	2257741	Louver
5	2311637	Wire Harness, Dual Crisper
6	2206270	Shelf Ladder
7	489478	Screw
8	W10004810	Screw (2)
9	2256035	Bracket, Dual Crisper Light
10	2256085	Bracket Retainer
11	489290	Screw
12	2209753	Air Diffuser Assembly
13	2152019	Air Diffuser Cover
14	2150331	Cover, Conduit
15	2162085	Socket
16	2256126	Reservoir
17	2255743	Light Bulb
18	2209769	Light Lens
19	488280	Screw

IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

REFRIGERATOR SHELF PARTS

For Models: MSD2258KGW01, MSD2258KGB01, MSD2258KES01, MSD2258KEU01
(White) (Black) (Stainless) (Stainless VCM)



Illus. No.	Part No.	DESCRIPTION
1	W10130773	Shelf Assembly, Spillguard
2	2188667	Snack Bin
3	2209698	Cover, Crisper
4	2196485	Stud Assembly
5	2174150	Glass, Cover
6	2179259	Glass, Cover
7	3400894	Screw
8	2311726	Cover, Meat Pan
10	2188652	Crisper Pan
11	2179343	Front, Crisper Pan
12	2179342	Slide, Humidity Control
13	2326317	Trim, Handle
14	2326284	Meat Pan
15	2326318	Shelf S/G
16	2195975	Frame Assy
17	2179350	Deflector
18	2326285	Trim, Handle
19	W10130774	Shelf, Snack Bin
20	2179243	Trim, Handle

IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

FREEZER LINER PARTS

For Models: MSD2258KGW01, MSD2258KGB01, MSD2258KES01, MSD2258KEU01
(White) (Black) (Stainless) (Stainless VCM)



IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

FREEZER LINER PARTS

For Models: MSD2258KGW01, MSD2258KGB01, MSD2258KES01, MSD2258KEU01
(White) (Black) (Stainless) (Stainless VCM)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Seviceable Part)
2		Track, Basket−Dual
	2301291	Right
	2301292	Left
3	2211743K	Shelf, Slide Out Lower (2)
4		Shelf Track
	2301289	Right Side
	2301290	Left Side
5	2212343K	Shelf (2)
6	2216111	Freezer Bin
7	W10004810	Screw (8)
8	842534	Clip, Air Duct (2)
9	2198587	Cover, Emitter
10	2198635	Spring
11	2198634	Pin
12	1115373	Switch, Rocker Arm
13	2220398	P.C. Board Emitter
14	2212321	Slide, Ice Maker
15	489478	Screw
16	489214	Screw
17	2162085	Light Socket
18	2255743	Light Bulb
19	8281185	Screw
20	2198633	Flipper
21	2326280	Cover, Receiver
22	2315398	Slide, Ice Maker Shut Off
23	2255114	P.C. Board, Receiver
24	2198643	Lens
25	2212376	Light Lens
26	2198641	Bracket, Ice Maker Cover
27		Ladder
	2320027	Left Side
	2320028	Right Side
28	2303234	Shield, Wiring

MOTOR AND ICE CONTAINER PARTS

For Models: MSD2258KGW01, MSD2258KGB01, MSD2258KES01, MSD2258KEU01

(White) (Black) (Stainless) (Stainless VCM)



IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

MOTOR AND ICE CONTAINER PARTS

For Models: MSD2258KGW01, MSD2258KGB01, MSD2258KES01, MSD2258KEU01
(White) (Black) (Stainless) (Stainless VCM)

Illus. No.	Part No.	DESCRIPTION
1	W10128699	Ice Bin
2	2317246	Crusher Bin
3	2317247	Auger
4	2258220	Washer
5	1119007	Spacer, Flat (4)
6	2317248	Cover, Crusher
7	2257024	Blade, Rotary
8	1119005	Spacer, Step
9	2257020	Blade, Fixed
10	2257023	Blade, Rotary
11	2317239	Block, Blade
12	489229	Roll Pin
13	2257022	Blade, Rotary
14	489235	Washer, Plain
15	2198661	Washer, Coupling
16	2188918	Coupling
17	8281164	Screw
18	3400065	Screw
19	2317243	Wiper
20	2317274	Latch, Bin
21	2198608	Spring, Latch
22	2317250	Divider, Chamber
23	8281163	Screw
24	2188919	Holder
25	2198628	Seal
26	2188916	Drive Shaft
27	2256154	Enclosure, Motor
28	2315547	Dispenser, Motor
29	2212305	Cover
30	2315559	Sleeve, Coupling
100	W10128701	Ice Container (Complete)

REFRIGERATOR DOOR PARTS

For Models: MSD2258KGW01, MSD2258KGB01, MSD2258KES01, MSD2258KEU01
(White) (Black) (Stainless) (Stainless VCM)



IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

REFRIGERATOR DOOR PARTS

For Models: MSD2258KGW01, MSD2258KGB01, MSD2258KES01, MSD2258KEU01
(White) (Black) (Stainless) (Stainless VCM)

Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door (Includes Item #8)
	2326298W	White
	2326298B	Black
	2326298S	Stainless
	2326298LG	Stainless VCM
2		Thimble, Top
	2308091	White, Black, and Stainless VCM
	2308050	Stainless only
3	2256101	Door, Compartment
4	2156022	Trivet, Shelf
6	2304235K	Door Bin (3)
8		Door Gasket, Magnetic
	2221300	Mist Beige
	2221311	Black
9		Handle
	67006114	White
	67006115	Black
	67006391	Stainless
10	3400012	Screw
11	2326259	Stud, Handle
12	13035001	Nameplate
13	2182178	Door Closer, Upper Cam
14	489420	Screw
15		Bracket, Door Stop
	2206629	White
	2206629B	Black
16	488208	Screw

FREEZER DOOR PARTS

For Models: MSD2258KGW01, MSD2258KGB01, MSD2258KES01, MSD2258KEU01
(White) (Black) (Stainless) (Stainless VCM)



IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

FREEZER DOOR PARTS

For Models: MSD2258KGW01, MSD2258KGB01, MSD2258KES01, MSD2258KEU01
(White) (Black) (Stainless) (Stainless VCM)

Illus. No.	Part No.	DESCRIPTION
1		Freezer Door (Includes Item #8 And Dispenser Front Parts)
	W10120261	White
	W10120267	Black
	W10128716	Stainless
	W10128718	Stainless VCM
2		Handle
	67006114	White
	67006115	Black
	67006391	Stainless
3	488500	Screw
4	2326259	Stud, Handle
5	2156021K	Trivet, FC
6		Door Gasket, Magnetic
	2221301	Mist Beige
	2221312	Black
7	2212375	Trim, Door Shelf
8	3400012	Screw
9	2187725	Wire Harness
10	2182179	Door Closer, Upper Cam
11	489420	Screw
12		Bracket, Door Stop
	2206629	White
	2206629B	Black
13	2154473	Connector
14		Thimble, Top
	2182181	White, Black and Stainless VCM
	2301049	Stainless only
15	488208	Screw

DISPENSER FRONT PARTS

For Models: MSD2258KGW01, MSD2258KGB01, MSD2258KES01, MSD2258KEU01
(White) (Black) (Stainless) (Stainless VCM)



IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

DISPENSER FRONT PARTS

For Models: MSD2258KGW01, MSD2258KGB01, MSD2258KES01, MSD2258KEU01
(White) (Black) (Stainless) (Stainless VCM)

Illus. No.	Part No.	DESCRIPTION
1		Housing, Dispenser (Not Serviced)
2	3196537	Screw
3	2194719	Retainer, Levers
4	2304772	Spring, Torsion
5	2196195	Pin
6	2180353	Door, Ice
7	2304355	Door Mechanism Assembly
8	2205686	Mechanism Delay
9		Grille, Overflow
	2206671W	White
	2206671B	Black
10	2304317	Water Fitting Assembly (Includes Water Tube)
11		Lever, Ice Dispenser
	2203562W	White
	2203562B	Black
12	2180224	Guide, Ice
13	2305571	Gasket
15	2323001	Bracket, Control
17		Lever, Water Dispenser
	2203561W	White
	2203561B	Black
19		Overlay, Front Cover (Not Available Order #23)
20		LED Display
21		Front Cover, Housing (Not Available, Order #23)
22	489000	Screw
23		Front Cover Assembly (Includes Items 19, 20 & 21)
	W10120285	White
	W10120286	Black
24	2252127	Sleeve, Delay Mechanism
25	2195051	Strain Relief
26	2304673	Bracket, Dispenser

UNIT PARTS

For Models: MSD2258KGW01, MSD2258KGB01, MSD2258KES01, MSD2258KEU01

(White) (Black) (Stainless) (Stainless VCM)



IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

UNIT PARTS

For Models: MSD2258KGW01, MSD2258KGB01, MSD2258KES01, MSD2258KEU01
(White) (Black) (Stainless) (Stainless VCM)

Illus. No.	Part No.	DESCRIPTION
1	2169104	Insulation, Sound
2	2225834	Fan, Blade
3	W10121484	Condenser Assembly
4	489464	Screw
5	2216914	Clip, Condenser
6	8533993	Screw
7	2217195	Heat Shield And Drain Pan
8	2205764	Tube Suction
9	W10132419	Bushing, COmpressor
12	4387731	Cover (Service Only)
13	2187145	Overload (Service Only)
14	2161324	Clip, Defrost Heater
15	2183454	Relay (Service Only)
16	2304884	Start−Device, Combination (Start Relay and Overload for Production Compressor Only)
17		Capacitor
	2264017	Production
	1118576	Service
18	2223314	Clip, Retaining
19	4387765	Wire, Capacitor (Service Only)
20	2304898	Unit Cover, Bottom
21	489396	Clip
22	2188822	Evaporator
24	2188874	Motor, Fan
25	1105523	Tray, Evaporator
26	2187783	Harness, Unit
27		Drier
	2319825	Production
	2317845	Service
28	W10120459	Compressor (Includes Items 12, 13, 15, 17, 19 & 27)
29	2304903	Frame, Unit Mounting
30	2181929	Bracket, Fan Motor
31	2188174	Heater, Defrost
32	2304287	Clip
33	489373	Screw
34		Grommet (4)
	1100826	Production
	4387558	Service
35	489340	Screw
36	2196202	Air Baffle
37	2155547	Clip, Heat
38	2149718	Unit Mounting Rail
39	8281232	Screw
40	2186496	Guard, Fan
41	2161302	Sleeve
42	489427	Screw
43	489478	Screw
44	2208280	Clip, Wire & Tube
45	2209709	Connector, Water Tube

Following Parts Not Illustrated and Optional Parts Not Included

978025	Valve, Access (1/4")
978026	Valve, Access (5/16")
978027	Valve, Access (3/8")
978028	Valve, Access (1/2")
978029	Valve, Access (5/8")
978030	Valve, Access (3/4")
876764	Valve, Access (3/16")

REFRIGERANT CHARGE

5.0 oz.
(R−134)

IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

ICEMAKER PARTS

For Models: MSD2258KGW01, MSD2258KGB01, MSD2258KES01, MSD2258KEU01
(White) (Black) (Stainless) (Stainless VCM)



IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

ICEMAKER PARTS

For Models: MSD2258KGW01, MSD2258KGB01, MSD2258KES01, MSD2258KEU01
(White) (Black) (Stainless) (Stainless VCM)

Illus. No.	Part No.	DESCRIPTION
1	489084	Screw
2	2256095	Fitting, Water Tube
3	628379	Clip, Fuse
4	489478	Screw
5	2188709	Filter Valve Asm
6	2208136	Clip, Tube
7	2174358	Cover
8	488649	Screw
9	2212351	Mold & Heater Assembly (Also Order 542638 Silicone Grease)
10	628356	Cup−Water Fill
11	2212320	Ejector
12	2212318	Ice Striper
13	2194712	Support
14	2315522	Retainer, Thermostat
15	627985	Thermostat (Also Order 542369 Cement Alumilastic)
16	8533917	Screw
17	489276	Screw
18	2187484	Harness, Wiring
19	W10131253	Bracket, Icemaker Mounting
20	626680	Module Assembly (Includes Items 21 & 22)
21		Motor (Not Serviced, Order #20)
22	489136	Screw
100	2212352	Complete Icemaker Assembly

CONTROL PARTS

For Models: MSD2258KGW01, MSD2258KGB01, MSD2258KES01, MSD2258KEU01
(White) (Black) (Stainless) (Stainless VCM)



Illus. No.	Part No.	DESCRIPTION
1	2181738	Control Box
2	2172931	Heat Shield
3	3196537	Screw (4)
4	2149705	Light Switch
5	2196001	Tube Barrier
6	2303824	Electronic Control
7	489398	Screw (2)
8	940014	Hole Plug
9	2315562	Thermostat
10	2181741	Slide, Air Control
11	2172906	Grommet
12	2161466	Slide, Thermostat
13	2179920	Light Bar (RC)
14	2161306	Pivot Arm
15	627068	Screw
16	2162085	Light Socket
17	2161307	Connecting Rod, Short
18	2255743	Light Bulb
19	2187868	Control Box Harness
20	1115374	Clip, Wiring
21	1115375	Clip, Wiring
22	2161308	Connecting Rod
23	489391	Fastener, Push−On
24	2326277	Escutcheon, Control Box
25	2179921	Light Bar (FC)
26	2175513	Window
27	489203	Spring Washer

IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

AIR FLOW PARTS

For Models: MSD2258KGW01, MSD2258KGB01, MSD2258KES01, MSD2258KEU01
(White) (Black) (Stainless) (Stainless VCM)



Illus. No.	Part No.	DESCRIPTION
1	2182119	Fan Scroll
2	2155590	Retainer, Fan Motor
3	2313359	Air Duct, Upper
4	2212313	Air Duct Freezer
5	2319914	Bi−Metal, Defrost
6	2315549	Fan Motor
7	2169142	Fan Blade
8	2304241	Gasket, Evaporator Cover (2)
9	2176759	Fan Grommet (2)
10	2310240	Harness, Fan Evaporator (Includes #5)
11	2155788	Gasket, Fan Scroll
12	2172840	Wire Tie
13	2203875	Gasket
14	2304908	Cover, Evaporator (Includes #8)
15	8281159	Screw (6)
16	489478	Screw
17	2203595	Support, R.S
18	2203596	Support, L.S

IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

OPTIONAL PARTS (NOT INCLUDED)

For Models: MSD2258KGW01, MSD2258KGB01, MSD2258KES01, MSD2258KEU01
(White) (Black) (Stainless) (Stainless VCM)

Illus. No.	Part No.	DESCRIPTION

PAINT, PRESSURIZED SPRAY (12 oz.)

	*350942	Primer, White
	*350939	Black
	*350930	White
	*8171357	Graphite

PAINT, TOUCH−UP (1/2oz.)

	72017	White
	72032	Black
	80051	Graphite

*__Important:__ The spray paint is not to be used where the paint may make contact with the door gaskets.

Illus. No.	Part No.	DESCRIPTION

PAINT, BULK (1 qt.)

	799340	Black
	799344	White
	8171358	Graphite

Miscellaneous

	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	505587	Sealer, Mastic (1 Qt.)
	503695	Cork, Sealer (1/4 Pound)
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1−1/4 Oz.)
	799833	Kit, Evaporator Repair (Aluminum Epoxy)
	833938	Kit, Terminal Connector

Illus. No.	Part No.	DESCRIPTION

TORX SCREW WRENCH

	1117510	Torx Key